



## Back




## Front




## Optional Hardware

### Audigy Sound Card



**REMEMBER:** Plug your audio equipment into the Audigy sound card instead of the on-board audio jacks.

### Internal Modem



Depending on the Talon model number and the optional hardware you ordered, these cards may be on the back of your computer in the expansion slots.